


PAN[®]19

Assembly and Maintenance Instructions



WABCO



PAN[®]19

Assembly and Maintenance Instructions



Edition 3

This publication is not subject to an updating service.
You will find the current version at
<http://www.wabco.info/8150100633>



© 2013
WABCO

Subject to change without notice
Version 02/04.2013
815 010 063 3

1 Important instructions and safety instructions. . . 3	6 Replacing the seals 22
1.1 General notes 3	6.1 Replacing the protection caps and the bushings of the guide pins. 22
1.2 Safety instructions 3	6.1.1 Disassembly 22
1.2.1 Risk of accidents 3	6.1.2 Assembly. 23
1.2.2 Risk of injury 3	6.2 Replacing the protective cap of the adjuster screw. 26
1.3 Repair and maintenance instructions. 4	6.2.1 Removing the protective cap. 26
2 Description of the mechanical sliding calliper disc brake 5	6.2.2 Fitting the protective cap 27
3 Checking the brake 8	6.3 Renewing the protection cap on the adjuster screw hexagon 28
3.1 Checking the adjustment 8	6.3.1 Removing the protective cap. 28
3.2 Checking the brake linings. 9	6.3.2 Fitting the protective cap 29
3.2.1 Optical indication of the wear limit 9	7 Replacing the brake cylinder 31
3.3 Checking the brake discs. 10	7.1 Removing the brake cylinder. 31
3.3.1 Checking the condition of the brake disc 11	7.2 Fitting the brake cylinder 31
3.3.2 Checking the disc runout. 11	8 Annex 33
3.4 Checking the bearing play of the guide pin . 12	8.1 WABCO tools 33
4 Replacing the brake linings 13	8.2 Widths across flats and tightening torques . 34
4.1 Removing the brake linings 13	8.3 Exploded view of the replacement parts . . 36
4.2 Checking the protection caps and the ability of the brake calliper to move 15	8.4 Procurement and disposal of spare parts. 37
4.3 Fitting the brake linings 16	8.4.1 Procurement of replacement parts . . 37
5 Replacing the brake. 20	8.4.2 Disposal of the brake parts 37
5.1 Removing the brake. 20	
5.2 Fitting the brake 20	

1 Important instructions and safety instructions

1.1 General information

This publication describes maintenance and repair of the disc brakes PAN®19 including the individual operations and work processes required to replace components using available repair kits.

This publication is directed at trained service technicians employed at workshops for commercial vehicles.

- Before you begin with maintenance, repair, replacing a part etc., carefully read all the safety instructions as well as the repair and maintenance instructions included this publication. These instructions must be observed to avoid personal injury or material damage.
- WABCO only guarantees the safety, reliability and performance of its products and systems if all instructions, notes and safety instructions are observed.

Before you perform any work on the vehicle (repair, maintenance, replacing parts, etc.), you must ensure the following:

- Only trained and qualified personnel may perform repairs on the vehicle.
- Always follow the specifications and instructions of the axle or vehicle manufacturer.
- Always comply with the Company and national accident prevention guidelines and Health and Safety regulations.
- Wear suitable protective clothing as the situation requires.
- The workplace has to be dry, as well as sufficiently lit and ventilated.

1.2 Safety information

1.2.1 Danger of accidents



Warning! Reduced braking effect or brake failure

- Regularly check the wear limits of brake linings and brake discs.
- Replace worn, scorched, glazed, or oily brake linings immediately.
- Immediately replace worn or damaged brake discs.
- Always replace brake linings by axle and use a new retaining system for brake linings and pressure plates.



WARNING! Rolling vehicle

- Position the vehicle on an even surface and secure it against rolling away with brake wedges.
- Only use approved devices to jack up and secure the vehicle.
- Make sure that the transmission is in neutral and the park brake has been applied.



WARNING! Rolling vehicle

- Make sure that the release screw of the spring brake cylinder is threaded completely in after completing the maintenance and installation work and check the functionality of the parking brake.

1.2.2 Risk of injury



CAUTION! Hazardous dusts

- Do not clean any soiled areas of the brake with compressed air or other high-pressure devices.



CAUTION! Heavy load

- A second technician must assist during removal and installation of the brake.



CAUTION! Brake action while working on the brake

- Attach a clearly marked note on the steering wheel saying that work is being performed on the vehicle and that the brake must not be touched.



CAUTION! Crushing of fingers

- Only grip the brake on the outside with your hands while moving the brake calliper or working on the brake.
- **Do not use motor-driven screw or torque tools!**



CAUTION! Falling brake parts and high tightening and loosening torques

- Use suitable equipment, such as a vice, to clamp the brake when performing repairs on the brake outside the vehicle.

1.3 Repair and maintenance instructions

For good handling and good braking characteristics it is essential that the disc brake is in flawless technical condition.

- If cast parts have been heavily damaged or are severely worn, (cracks for example), replace the entire brake following the instructions.
- Never use the lining retainer (38) as a grab handle or for fastening a lifting device, because the retainer can be damaged in the process.
- **Do not open the brake calliper with the clamping unit, and do not unscrew the fastening screws on the brake calliper cover.**
- Do not apply the brake when brake linings have been removed.
- Do not use compressed air or other high-pressure devices when cleaning the brake or the vehicle. This may result in the risk of personal injury or hazardous dusts. Rubber parts of the brake could also be damaged.
- Only use original WABCO parts and approved brake linings and retaining systems for brake linings and pressure plates. An exploded view of replacement parts is found in the annex of this document (see chapter 8.3 „Exploded view of the replacement parts“, page36).
- Only use grease contained in the repair kits.
- Perform the repair work using only the recommended tools (see chapter 8.1 „WABCO tools“, page33). **Do not use motor-driven screw or torque tools!**
- Tighten screws and nuts only with the specified spanners, applying only the specified tightening torque; refer to the table in Annex (see chapter 8.2 „Widths across flats and tightening torques“, page34) for the corresponding positions.
- Perform a concluding roller test stand test having completed the repairs. If no roller test stand is available, conduct a test drive with brake action tests.
- Do not perform full braking, with the exception of emergency braking, during the first 50 km after new brake linings have been fitted. Also avoid continuous braking over longer periods. Ensure that the driver of the vehicle is informed.

2 Description of the mechanical sliding calliper disc brake

The PAN[®]19 brake is a pneumatic one-piston brake. It is designed for use in commercial vehicles and trailers on front and rear axle as service, auxiliary and parking brakes for 19.5" and 22.5" wheel rims. It is actuated mechanically via a diaphragm brake cylinder or a spring brake actuator. The latter is fitted directly onto the brake calliper, thereby reducing the overall axial length of the brake. This enables optimal utilisation of the installation situations.

The entire disc brake consists of brake cylinder, brake calliper (1), and brake anchor plate (2).




Fig. Entire disc brake

1 Brake calliper

2 Brake anchor plate

Arrow Brake calliper shifting directions

Functional description

More information is provided in the illustrations below.

Axial movement of the brake calliper (1) occurs on the guide pins (8, 9) of the brake carrier (2). The brake linings (35, 36) are guided and supported axially movable in the brake carrier. The brake lining support is implemented by means of a retainer (38) and hold-down springs (37).

The radially open design of the brake calliper enables simple and quick brake lining replacements. Linings with a large wear volume are used in order to prolong the replacement intervals.

For compensating the pad wear the actuating mechanism of the brake is equipped with a force-dependent, stageless, automatic adjuster mechanism. This mechanism maintains a preset clearance regardless of load and operating conditions. This, together with the stable and stiff construction of the brake calliper, results in safe control of the pedal travel and increases the reserve of travel for emergency braking.

All rubber parts and the grease fillings are maintenance-free except when damaged.

The disc brake is optionally equipped with an electrical wear indicator (threshold indicator).

When the indicator in the vehicle lights up, the residual lining thickness has been reached. It is necessary to drive the vehicle to a workshop for the brake linings to be replaced.




Fig. Top view and sectional view (left brake)

- | | | | |
|------|-----------------------|----|--|
| 1 | Brake calliper | 13 | Protection cap of the adjuster |
| 2 | Brake anchor plate | 19 | Spreader plate |
| 6 | Hexagon socket screw | 22 | Hexagon of the adjuster |
| 8 | Guide pin (long) | 37 | Hold-down spring |
| 9 | Guide pin (short) | 40 | Cable guide with wear indicator |
| 11 | Closing cover (short) | 41 | Retaining clip |
| 11.1 | Closing cover (long) | A | Forward driving, direction of rotation |




Fig. Side view and sectional view (left brake)

- 12 Sealing plug for adjustment
- 19 Spreader plate
- 35 Brake lining rim side
- 36 Brake lining cylinder side

- 37 Hold-down spring
- 38 Lining retainer
- 39 Hexagon screw
- A Forward driving, direction of rotation

3 Checking the brake



CAUTION! Risk of injury

- Observe all safety, repair and maintenance instructions (see chapter 1 „Important instructions and safety instructions“, page3).
- These instructions must be observed to avoid personal injury or material damage.


! The brake cylinder does not need to be dismantled in order to check the brake. The brake is shown without the brake cylinder for illustration purposes only.

3.1 Checking the adjuster

! Directions of rotation and torques of the hexagon nut of the adjuster are listed in the table in the annex (see chapter 8.2 „Widths across flats and tightening torques“, page34, item I).


Brake linings and pressure plate must be fitted in order to check the adjuster.

- Remove the sealing plug (12) of the adjuster.




! When removing the sealing plug, apply the respective tool (such as a screwdriver) only to the sealing plug

and do not damage the closing cover (13) or the brake calliper.



- Check the protection cap (13) for wear and damage.
- If the protection cap (13) of the adjuster is damaged, renew it (see chapter 6.3 „Renewing the protection cap on the adjuster screw hexagon“, page28).
- Use the ring spanner (tools 12 and 13) to turn the hexagon (22) of the adjuster a ½ turn in clockwise direction (see chapter 8.2 „Widths across flats and tightening torques“, page34, item I).



! The adjuster can only be checked with increased clearance.

There must be sufficient space for the engaged ring spanner; it must not be obstructed when it is turned during adjustment.

Do not use an open-end spanner for the hexagon (22) of the adjuster and never overstrain the hexagon nut. Otherwise the hexagon will be damaged.

- Gently apply the brake 5 times (braking pressure approx. 1 bar).

If the adjuster functions correctly, the ring spanner will turn anticlockwise incrementally.

- With increasing adjustment the angle of rotation of the engaged ring spanner becomes smaller. The adjuster is working correctly if the ring spanner rotates anticlockwise as described above.

Faults that might occur:

The engaged ring spanner

- not
- rotate with the initial brake action
- rotate forward and backward with every brake action

In these cases the adjuster is faulty and the brake must be replaced (see chapter 5 „Renewing the brake“, page20).

- Reset the clearance to 1 mm having completed the adjuster test (see chapter 4.3 „Fitting the brake linings“, page16).
- Remove the ring spanner (tools **12** and **13**) from the hexagon nut of the adjuster (22).
- Insert the sealing plug (12) into the adjuster and ensure that the plug has a tight seat.


3.2 Checking the brake linings

- The brake lining thickness must be checked at regular intervals, in relation to vehicle use, during maintenance intervals, as well as in the context of applicable local laws and regulations.

Burned, glazed or oil contaminated brake linings must be replaced immediately.

Always replace all brake linings by axle, using a new retaining system for brake linings and pressure plates.

To avoid damaging the brake disc replace the brake linings no later than at the point when they reach the wear limit at their weakest spot. The residual lining thickness must not be allowed to become less than 2 mm above the backing.




- A Lining thickness without backing (limit value 2 mm residual thickness)
- B Lining thickness new without backing (21 mm)
- C Total thickness new lining with backing (30 mm)
- D Backing
- H Brake lining

3.2.1 Optical indication of the wear limit


Wear on the middle of the lining can be measured with a tape measure or a ruler either at the fit bolt (long guide pin near the disc run in) or at the play bolt (short guide pin near the disc run out).

- Place the ruler onto the surface (hatched area in the picture, arrow) of the brake anchor plate.



- The measuring point on the brake anchor plate is the machined bearing surface of the screwed joint of the respective guide pin (arrow on the hatched area).

- Measure the distance from the area on the brake anchor plate (left arrow) to the edge of the guide pin (right arrow) on the brake calliper.



If the distance measured

- at the short guide pin is greater than **96 mm**,
 - at the long guide pin is greater than **122 mm**,
- the wear limit has been reached.
- Replace the brake linings if the wear limit has been reached or it has been exceeded (see chapter 4 „Replacing the brake linings“, page13).

3.3 Inspecting the brake discs


- Regularly check the wear limits of brake linings and brake discs.

When brake linings and/or brake discs are worn, the braking effect is reduced and there is a risk of brake failure. Replace brake discs and brake linings.

Always replace all brake discs by axle.


The brake discs must be clean and free from grease!

Having installed new brake discs, it is recommended that new brake linings be fitted as well.



- A Lining thickness with lining support (limit value 11 mm residual lining thickness)
 - C Total thickness new lining with backing (30 mm)
 - D brake lining supporting plate (9 mm)
 - E Residual brake lining thickness (2 mm)
 - F Overall thickness new brake disc (45 mm)
 - G Wear measurement limit (at least 37 mm)
- Remove the brake linings (see chapter 4.1 „Removing the brake linings“, page13).
 - Measure the brake disc thickness at the contact area of the brake linings.
 - Replace the brake disc if the wear measurement limit of 37 mm has been reached at the thinnest point.


3.3.1 Checking the condition of the brake disc



- A Web-like crack formation: permissible
 - B Radial cracks up to max. 0.5 mm width: permissible
 - C Unevenness of the disc surfaces up to max. 1.5 mm deep: permissible
 - D Continuous cracks: not permissible
 - a Width of the braking area
- Check the brake disc for cracks and the condition of the surface.
 - Replace the brake disc if the brake disc has continuous cracks or cracks or unevenness in excess of the permissible max. dimensions.

3.3.2 Checking the disc runout



- Fasten the dial indicator to the brake calliper.
- With the brake disc installed, check the disc runout by rotating the wheel hub. Limit value: 0.15 mm




- Replace the brake disc or have it properly reworked if the brake disc runout is more than 0.15 mm.
- Install the brake linings, and adjust the clearance (see chapter 4.3 „Fitting the brake linings“, page16).

3.4 Checking the bearing play of the guide pin


- Remove the vehicle wheel and then the brake linings and the pressure plate (see chapter 4.1 „Removing the brake linings“, page13).
- Push the calliper completely to the rim side by hand.
- Fasten the magnetic dial indicator support to the brake carrier or the axle.
- Clean the measuring point. The measuring point is the moulded edge on the brake calliper on the rim side.
- Press the dial indicator against the measuring point (arrow) on the brake calliper.



- Applying little force, tilt the brake calliper as far as possible (direction as illustrated in picture) and set the dial indicator to the value zero.



- Now, and again applying little force, tilt the brake calliper as far as possible in the opposite direction.



- Read the dial indicator. **The bearing play must not be greater than 2 mm.**
- Remove the measurement device.
- Renew the bushings of the guide pins if the measured bearing play is greater than 2 mm (see chapter 6.1 „Renewing the protection caps and the bushings of the guide pins“, page22).
- Fit the pressure plate and the brake linings, adjust the clearance and mount the vehicle wheel (see chapter 4.3 „Fitting the brake linings“, page16).

4 Replacing the brake linings



CAUTION! Risk of injury


- Observe all safety, repair and maintenance instructions (see chapter 1 „Important instructions and safety instructions“, page3).
- These instructions must be observed to avoid personal injury or material damage.

I The brake cylinder does not need to be dismantled in order to replace the brake linings. The brake is shown without the brake cylinder for illustration purposes only.

Always replace the brake linings by axle and use a new retaining system for brake linings and pressure plates.


4.1 Removing the brake linings

- Remove the vehicle wheel in accordance with the instructions of the axle or vehicle manufacturer.
- Disconnect the plug connection (arrow) of the wear indicators (40).
- Remove the hexagon head screw (39) from the lining retainer (38) (see chapter 8.2 „Widths across flats and tightening torques“, page34, item II).
- The lining retainer (38) has to be withdrawn from the calliper (1).




- Remove the cable guide (40) with the wear indicators.

- Remove three hold-down springs (37) from the brake linings (35 and 36) and the pressure plate (19).
- Remove the cable clips (41) from the calliper.




- Remove the sealing plug (12) of the adjuster.

I When removing the sealing plug, apply the respective tool (such as a screwdriver) only to the sealing plug and do not damage the closing cover (13) or the brake calliper.



- Check the protection cap (13) for wear and damage.
- If the protection cap (13) of the adjuster is defective, renew it (see chapter 6.3 „Renewing the protection cap on the adjuster screw hexagon“, page28).
- Use a ring spanner (tools 12 and 13) to turn the hexagon (22) of the adjuster clockwise to the stop


position and then turn the hexagon back in anticlockwise direction by 90°.




- While turning the hexagon (22), use your hand to push the pressure plate (19) towards the cylinder side to ensure that the pin as an antirotation lock for the adjuster screw (21) does not slip out of the retaining groove of the pressure plate.

Otherwise there is a risk of the adjuster screw turning simultaneously, which could damage the protection cap (10).

- Push the calliper (1) towards the rim side by hand (arrow).
- Remove the brake lining (35) on the rim side.




- Push the calliper (1) towards the cylinder side by hand (arrow).
- Remove the brake lining (36) and pressure plate (19) on the cylinder side.



! Do not apply the brake when brake linings have been removed. There is the risk of injury and the risk of damaging the brake!

- Check the pressure plate (19) for corrosion and damage. **Renew the pressure plate if you have identified damage. Always replace the pressure plate axle by axle.**
- Use a wire brush to clean pressure plate, lining slots and pressure plate guide, and remove any corrosion on these components.


Take care not to damage the protection caps (5, 10) while cleaning.



! The guide surfaces of the lining slots on the brake carrier must be **clean and free of grease!**

4.2 Checking the protection caps and the ability of the brake calliper to move

- Push the calliper (1) towards the cylinder side (arrow).
- Check the protection caps (5, 10) for the guide pins (8, 9) and the adjuster screw (21) for wear and damage.
- Renew any defective protection caps (see chapter 6.1 „Renewing the protection caps and the bushings of the guide pins“, page22 and see chapter 6.2 „Renewing the protection cap of the adjuster screw“, page26).




- If the protection cap (10) is damaged, check whether dirt or moisture has penetrated into the brake's interior parts or have damaged the calliper due to corrosion.

Renew the brake if you have identified damage or corrosion (see chapter 5 „Renewing the brake“, page20).

- Renew the protection caps if they are damaged during service work on the brake.
Drehen Sie mit dem Ringschlüssel (Werkzeuge **12** und **13**) den Sechskant (22) der Nachstellung im Uhrzeigersinn bis die Nachstellschraube (21) ca. 30 mm herausgeschraubt ist.

Prüfen Sie dabei die Leichtgängigkeit der Bewegung

- Manually move the brake calliper on the guide pins across the entire displacement path and check for ease of movement.



- Do not squeeze the guide pin protection caps against the brake carrier while moving the calliper.


- Replace the bushings, guide pins and protection caps if the calliper moves sluggishly (see chapter 6.1 „Renewing the protection caps and the bushings of the guide pins“, page22).
- Manually check the adjuster.

- Secure the adjuster screw (21) against twisting when performing the test and when turning the hexagon (22) by arresting the pin (arrow) of the adjuster screw.



- Use the ring spanner (tools **12** and **13**) to turn the hexagon (22) of the adjuster clockwise until the adjuster screw (21) is unscrewed about 30 mm.

- Check for ease of movement.




I Do not use an open-end spanner for the hexagon (22) of the adjuster and never overstrain the hexagon nut. Otherwise the hexagon will be damaged.

- Use the ring spanner to turn the hexagon (22) clockwise back to the stop.
When turning back (clockwise) the torque is greater than when turning anticlockwise.
- If appropriate, check the adjuster for correct function (see chapter 3.1 „Checking the adjuster“, page8).

4.3 Fitting the brake linings

- To insert the pressure plate and the brake linings on the cylinder side, push the calliper towards the cylinder side until there is sufficient distance to the brake disc.
- Insert the pressure plate (19) into the brake carrier and push the pressure plate against the adjuster screw (21).




I Ensure that the pressure plate is seated in the guide groove of the brake anchor plate and that it rests with the entire surface on the guide strips of the brake anchor plate. Otherwise the pressure plate could slide out of the guiding.


If required, push the calliper a little towards the rim side.

The pin of the adjuster screw must mesh with the groove (arrow) of the pressure plate, otherwise the adjustment will not function. Turn the adjuster screw until the pin meshes with the groove of the pressure plate. Ensure that the protection cap is not twisted.

- Fit a **new** brake lining (36) on the cylinder side.
- Push the calliper towards the rim side until the brake lining (36) of the cylinder side bears against the brake disc.



- Fit a **new** brake lining (35) on the rim side.
- Adjust the clearance by means of a 1 mm feeler gauge (arrow). For this purpose insert the feeler gauge between the brake lining of the rim side and the calliper. Turn the hexagon (22) of the adjuster anticlockwise with a ring spanner (tools 12 and 13) until both brake linings bear on the brake disc.




- Always insert the feeler gauge into the centre between brake calliper (1) and brake lining support plate (35).

Do not use an open-end spanner for the hexagon (22) of the adjuster and never overstrain the hexagon nut. Otherwise the hexagon will be damaged.


Mount the lining retainer pin only **after** you have adjusted the clearance.

- Remove the sensor gauge and insert two **new** cable clips (41) into the brake calliper.
- Place the **new** cable guide plate (40) with **new** preassembled wear indicators onto the brake calliper and insert the indicators (circles) into the brake linings.




- Ensure that each wear side of the indicators points towards the brake disc and that the indicators are inserted completely into the brake lining.

- Lift the cable guide plate (40) a little and push **three new** hold-down springs (37) under the cable guide plate onto the brake linings (35, 36) and the pressure plate (19).




- When laying the cable, ensure that the cable does not touch the brake lining.

- Press the cable guide plate (40) against the hold-down springs and position it on the brake calliper.





- Push a **new** lining retainer (38) into the openings (white arrows) of the brake calliper and press the lining retainer so that the bracket meshes between the radial lugs of the hold-down springs.



- Make sure that the lining retainer (38) is above the wear indicator cables.

- Fasten a **new** hexagon screw (39) to the brake calliper (see chapter 8.2 „Widths across flats and tightening torques“, page 34, item II).
- Remove the transport protection cap from the wear indicator connector if in place.
- Connect the connectors of the wear indicators to the plug socket of the vehicle or the axle.
- Fasten the cable to the **new** cable clip (41).
- Ensure that the cable has been laid correctly and fix the cable in position using cable ties.
- Push a **new** sealing plug (12) into the opening of the brake calliper. Make sure that the plug has a tight seat.



- Check the wheel hub for ease of movement.
- Mount the vehicle wheel in accordance with the instructions of the axle or vehicle manufacturer.

! Having completed the work, test the brake on a roller test stand.

5 Renewing the brake



CAUTION! Risk of injury

- Observe all safety, repair and maintenance instructions (see chapter 1 „Important instructions and safety instructions“, page3).
- These instructions must be observed to avoid personal injury or material damage.

Never use the lining retainer (38) as a grab handle or for fastening the brake to a lifting device, because the retainer can be damaged in the process.


The **new** brake without brake lining is supplied as a pre-assembled unit and may be mounted to the vehicle's axle via the brake carrier.

Left and right brake must not be interchanged when they are installed on the axle. An arrow on the brake calliper indicates which brake is correct for the left and which for the right axle side. This arrow indicates the brake disc's direction of rotation during forward driving.

5.1 Removing the brake

The illustrations of the brake anchor plate are for example only and may deviate from the actual brake design.

- Remove the vehicle wheel in accordance with the instructions of the axle or vehicle manufacturer.
- Remove the brake linings (see chapter 4.1 „Removing the brake linings“, page13).
- Remove the brake cylinder from the calliper (see chapter 7.1 „Removing the brake cylinder“, page31).



- Disconnect the plug connection of the wear indicators.
- Remove the brake calliper with brake anchor plate from the axle (see chapter 8.2 „Widths across flats and tightening torques“, page34, item III).
- Check the brake disc (see chapter 3.3 „Inspecting the brake discs“, page10).
- Check the dismantled brake linings and replace if necessary (see chapter 3.2 „Checking the brake linings“, page9).
- Check the fastening flange on the axle for wear and damage.
- Clean the fastening flange on the axle and remove any dirt, rust and grease.

5.2 Installing the brake



When fitting the brake follow the mounting instructions of the axle or vehicle manufacturer, and make sure you do not mismatch the right and left brake.

- Place the brake with brake anchor plate on top of the brake disc and mount the brake to the axle.



- Tighten the hexagon screw (see chapter 8.2 „Widths across flats and tightening torques“, page34, item III). Always observe the assembly instructions of the axle or vehicle manufacture.

- Remove **all** transport locks from the **new** brake. The protection film (arrow) or the transport protector cap must be fully removed from the brake calliper in the area of the cylinder fastening.
- Mount the brake cylinder on the calliper (see chapter 7.2 „Installing the brake cylinder“, page 31).



- Install pressure plate, brake linings, and wear indicators, and adjust the clearance (see chapter 4.3 „Fitting the brake linings“, page 16).
- Connect the wear indicator connector to the socket on the vehicle or the axle and fasten the cable to the cable clip (41) of the brake calliper.
- Ensure that the cable has been laid correctly and fix the cable in position using cable ties.
- Inspect the brake cylinder for damage, particularly at the inner area of the piston-rod seal. **Renew the brake cylinder if you have identified damage.** (see chapter 7 „Replacing the brake cylinder“, page 31). **A defective brake cylinder must not be fitted again.**
- Clean the sealing surface and the flange area of the brake cylinder.

- ! Depending on the installation position of the brake, ensure that the lower drainage aperture of the brake cylinder facing the ground is open.

Depending on the actuator type, the other drainage openings can either remain open or they must be sealed with a plug. Observe the respective instructions of the brake cylinder manufacturer.

- Check whether the wheel hub moves freely.
- Mount the vehicle wheel in accordance with the instructions of the axle or vehicle manufacturer.

- ! Having completed the work, test the brake on a roller test stand.

6 Renewing the seals



CAUTION! Risk of injury

- Observe all safety, repair and maintenance instructions (see chapter 1 „Important instructions and safety instructions“, page3).
- These instructions must be observed to avoid personal injury or material damage.

Never use the lining retainer (38) as a grab handle or for fastening the brake to a lifting device, because the retainer can be damaged in the process.

If all seals of the brake calliper are replaced, the work sequences for renewing the protection caps and bushings of the guide pins, as well as the protection cap of the adjuster screw can be performed together.

If the seals were individually replaced however, the step sequences are to be performed individually as described in the respective sections (Kapitel 6.1 and Kapitel 6.2).


The illustrations are for example only and may deviate from the actual design.

6.1 Renewing the protection caps and the bushings of the guide pins

6.1.1 Disassembly


- Remove the vehicle wheel in accordance with the instructions of the axle or vehicle manufacturer.
- Remove brake linings, the brake cylinder and the brake calliper with brake anchor plate from the axle (see chapter 5.1 „Removing the brake“, page20).
- Use a suitable fastening device (e.g. a vice) to clamp the brake to the brake carrier.

- Remove the closing covers (11, 11.1) of the pin guide (8, 9) from the brake calliper (1).



- When removing the sealing plug, apply the respective tool (such as a chisel) only to the closing cover and do not damage the seat of the closing cover on the brake calliper.


- Unscrew the screws (6) (see chapter 8.2 „Widths across flats and tightening torques“, page34, item IV), and remove the brake calliper (1) from the brake carrier (2).



Risk of injury! Moving brake calliper: risk of injury!

- Clean the contact areas (fitting collars) to the guide pins on the brake carrier (2).
- Remove the guide pins (8, 9) from the brake calliper (1).

- Pull the protection cap (5) out of the ring groove of the brake calliper (1).




- Place the brake calliper (1) on a firm base for pressing out the bushings (4). The cover opening of the brake calliper must face upwards.



Use WABCO tools (see chapter 8.1 „WABCO tools“, page 33) to replace the bushings.

- Use tools 10, 11 and 21 to press the bushings (4) out of the brake calliper (1).




- Clean the bores in the calliper.


6.1.2 Assembly

Press in two **new** bushings for the long guide pin.

- Use tools 10, 11 and 25 to press the inner bushing (4) into the bores of the brake calliper (1) on the brake disc entry side right to the end stop of the tool.




- Use tools 10, 11 and 22 to press the outer bushing (4) into the same bore right up to end stop of the tool.




- Grease the sliding surfaces of the bushings and the space between them.
- Use tools 10, 11 and 26 to press a **new** bushing (4) for the short guide pin into the bore of the brake

calliper (1) on the brake disc exit side right to the end stop of the tool.




(8, 9). Make sure that the metal ring (arrow) does not come off the protection cap in the process.



Ensure that the beaded edge of the protection caps (5) have an even and wrinkle-free seat in the sealing seats of the guide pins (8, 9).

- Grease the sliding surface of the bushing.
- Clean the sealing seats (ring groove) of the brake calliper for the protection caps. The cleaned sealing seats must be **clean and free from grease**.
- Manually push **new** green protection caps (5) into the sealing seats (ring groove, arrow) of the brake calliper (1).




Ensure that the beaded edge of the protection caps (5) have an even and wrinkle-free seat on the brake calliper (1).

- Grease the bearing surfaces of the guide pins (8, 9) and the beaded edge of the protection caps (5).
- Insert a **new** long guide pin (8) into the brake calliper (disc brake entry side) from the cylinder side.
- Insert a **new** short guide pin (9) into the brake calliper (disc brake exit side) from the cylinder side.
- Slide the protection caps (5) over both WABCO guide pins.
- Position the beaded edge of the protection caps (5) into the sealing seats (ring grooves) of the guide pins


- Remove any excess grease. **The plane surfaces of the guide pins to the brake carrier and the contact areas of the brake carrier must be clean and free of grease.**

- Manually move the guide pins in the bushings lightly back and forth and check for ease of movement.



- Place the calliper (1) on the brake carrier (2) and the inserted guide pins (8, 9) into the fitting collar.
- Insert two **new** screws (6) through the guide pins inserted in the brake calliper (1).

- Fasten the screws to the brake anchor plate (2) (see chapter 8.2 „Widths across flats and tightening torques“, page34, item IV).




- ! During assembly, ensure that the protection caps (5) are not damaged or twisted while tightening the screws (6).

Always tighten the longer guide pin (8) with press-fit first and then the shorter guide pin (9) with clearance.


If the guide pins (8, 9) are released from the brake carrier (2) during the maintenance work, **new** screws (6) must be used for reassembly.

- Manually move the brake calliper on the guide pins (8, 9) across the entire displacement path and check for ease of movement; repeat the action a number of times.



- ! Do not squeeze the guide pin protection caps against the brake carrier while moving the calliper.

- Grease the bores for the closing cover (11, 11.1) in the brake calliper (1).
- Push the brake calliper (1) against the brake carrier.
- Insert the **new** closing covers (11, 11.1) into the bores of the brake calliper (1). Use the long closing cover (11.1) for the long guide pin (8) and the short closing cover (11) for the short guide pin (9).
- Use tools **10**, **11** and **27** to press the closing cover down to the stop position.




- ! Avoid damaging the lids while pressing them in.

- Check the connecting surface on the fastening flange of the axle and the brake carrier and remove any dirt, rust or oil.
- Place the brake with brake anchor plate on top of the brake disc and mount the brake to the axle.(see chapter 5.2 „Installing the brake“, page20).

Always observe the assembly instructions of the axle or vehicle manufacture.

- Install pressure plate, brake linings, and wear indicators, and adjust the clearance (see chapter 4.3 „Fitting the brake linings“, page16).

- Clean the sealing area (A) and the flange surface (B) on the brake calliper and grease the calotte in the brake lever (C).



■ Ensure that no dirt or moisture enters the brake when cleaning.

- Check the brake cylinder for damage, particularly at the inner area of the piston-rod seal. **Renew the brake cylinder if you have identified damage.** (see chapter 7 „Replacing the brake cylinder“, page31). **A defective brake cylinder must not be fitted again.**
- Clean the sealing surface and the flange area of the brake cylinder.
- Mount the brake cylinder on the calliper(see chapter 7.2 „Installing the brake cylinder“, page31).

Always note the relevant specifications of the axle or vehicle manufacturer during this procedure and strictly adhere to them.

■ Depending on the installation position of the brake, ensure that the lower drainage aperture of the brake cylinder facing the ground is open.

Depending on the actuator type, the other drainage openings can either remain open or they must be sealed with a plug. Observe the respective instructions of the brake cylinder manufacturer.

- Check whether the wheel hub moves freely.
- Mount the wheel in accordance with the instructions of the axle or vehicle manufacturer.


■ Having completed the work, test the brake on a roller test stand.

6.2 Renewing the protection cap of the adjuster screw

■ If the protection caps are removed individually, brake calliper and brake cylinder need not be dismantled.



6.2.1 Removing the protection cap

- Remove the brake linings and the pressure plate (see chapter 4.1 „Removing the brake linings“, page13).
- Push the calliper completely to the cylinder side by hand.
- Pull the protection cap (10) from the sealing seat (ring groove) of the adjuster screw (21).




- Remove the protection cap (10) from the sealing seat of the brake calliper with a screwdriver. Make sure you do not damage the sealing seat of the protection cap in the brake calliper in the process.
- Check the brake calliper. If dirt or moisture has entered the brake, or if the sealing seat in the brake calliper or the thread of the adjuster screw (21) is damaged, replace the brake (see chapter 5 „Renewing the brake“, page20).

- Fit the rim side brake lining into the lining slot so that the adjuster screw cannot be screwed out of the adjuster completely.
- Clean the sealing seats (arrows) of the protection cap (10) in the brake calliper and the ring groove of the adjuster screw (21).



- Secure the adjuster screw (21) on the pin against twisting.
- Use tools **12** and **13** to turn the hexagon (22) anticlockwise until the adjuster screw has been screwed outwards approx. 30 mm by this action (see chapter 8.2 „Widths across flats and tightening torques“, page34, item I).



- While threading it out, check the thread of the adjuster screw (21) for corrosion and damage. If the thread and/or visible internal brake parts are damaged or corroded, replace the brake (see chapter 5 „Renewing the brake“, page20).

Ensure that no dirt or moisture enters the brake when cleaning. **The sealing seat for protection cap (10) in the brake calliper must be clean and free from grease.**


- Grease the thread of the adjuster screw (21).
- Use a ring spanner to turn the hexagon (22) anticlockwise until the adjuster screw has been partially turned inwards through this action. The adjuster screw pin must be in the same position as it was before it was screwed out.
- Remove the brake lining from the lining slot on the rim side.

6.2.2 Fitting the protection cap

- Slide a **new and grease-free** protection cap (10) over the adjuster screw.
- Centre the protection cap and it into the sealing seat of the brake calliper (1) by hand.
- Lightly grease the inner beaded edge of the protection cap (10).

The protection cap (10) can be renewed if it is certain that no dirt or water has penetrated into the brake calliper, or if the protection cap has been damaged during maintenance work.

- Insert the beaded edge of the protection cap (10) into the sealing seat (arrow) of the adjuster screw (21).



- Ensure that the cap has a correct sealing seat in the brake calliper (1) and that the beaded edge of the protection cap (10) has an even and wrinkle-free seat in the ring groove of the adjuster screw (21).


- Install the pressure plate and the brake linings, and set the clearance (see chapter 4.3 „Fitting the brake linings“, page16).

6.3 Renewing the protection cap on the adjuster screw hexagon


- If the protection caps are removed individually, brake calliper and brake cylinder need not be dismantled.

6.3.1 Removing the protection cap


- Remove the sealing plug (12) of the adjuster.



- Use a suitable tool (e.g. screwdriver) to press the protection cap (13) out of the brake calliper seat and remove the protection cap (13) from the hexagon (22) of the adjuster.



- Clean the sealing seats (arrows) of the protection cap (13) in the brake calliper.




Ensure that no dirt or moisture enters the brake when cleaning.

- Check the brake calliper. If dirt or moisture has entered the brake, or if the sealing seat in the brake calliper or the hexagon (22) of the adjuster screw is damaged, replace the brake (see chapter 5 „Renewing the brake“, page 20).

The protection cap (13) can be renewed, if definitely no dirt or water has penetrated into the brake calliper, or if the protection cap has been damaged in the process of servicing the brake.


6.3.2 Fitting the protection cap

- Place the mounting cap (A) onto the hexagon (22) of the adjuster and push the mounting cap right up to the stop position.




- Grease a **new** protection cap (13) only lightly at the inner sealing bead (arrow).
- Place the protection cap (13) onto the mounting cap (A).


- Manually press the protection cap (13) right to the stop in the brake calliper seat.




- Place the mounting bushing (B) onto the mounting cap (A).
- Press the mounting bushing (B) against the inner sealing bead of the protection cap (13) until the sealing bead lies in the ring groove of the adjuster.



- Remove the mounting bushing (B) and the mounting cap (A).
- Make sure that the protection cap (13) is fully inserted in the sealing seat of the brake calliper and the ring groove (arrow) of the adjuster.



- Push a **new** sealing plug (12) into the protection cap (13) of the adjuster. Ensure that the sealing plug (12) has a tight seat.



7 Replacing the brake cylinder



CAUTION! Risk of injury

- Observe all safety, repair and maintenance instructions (see chapter 1 „Important instructions and safety instructions“, page3).
- These instructions must be observed to avoid personal injury or material damage.

- Only use brake cylinders as specified by the axle or vehicle manufacturer.

The instructions for breaking the brake cylinder in are for general information. Pay attention to the installation specifications and the test and installation instructions of the brake cylinder manufacturer and strictly adhere to them.


The illustrations are for example only and may deviate from the actual design.

7.1 Removing the brake cylinder

- Unscrew the air connection from the brake cylinder.

- Ensure that the air connections of the brake cylinder are not pressurised.


- Unscrew the brake cylinder nuts (see chapter 8.2 „Widths across flats and tightening torques“, page34, item V).
- Remove the brake cylinder from the brake calliper.



- Ensure that no dirt or moisture enters the brake when removing the brake cylinder.


7.2 Installing the brake cylinder

- Clean the sealing area (A) and the flange surface (B) on the brake calliper and grease the calotte in the brake lever (C).



- Ensure that no dirt or moisture enters the brake when cleaning.

- Place the brake cylinder onto the brake calliper and manually screw on the brake cylinder using **new** fastening screws until the brake cylinder makes full contact with the brake calliper.



- Tighten the brake cylinder with around 120 Nm.
- Tighten the fastening nuts with approx. 210 – 30 Nm (see chapter 8.2 „Widths across flats and tightening torques“, page34, item V).

- Always use new fastening nuts when fitting the brake cylinder.

Depending on the installation position of the brake, ensure that the lower drainage aperture of the brake cylinder facing the ground is open.

Depending on the actuator type, the other drainage openings can either remain open or they must be sealed with a plug. Observe the respective instructions of the brake cylinder manufacturer.

-
- Screw the air connection onto the brake cylinder.

! Observe the respective instructions of the brake cylinder manufacturer here.

- Ensure that the brake hose is not twisted and routed so that it does not rub against the other parts.
- Ensure that the brake hose does not exert initial stress on the sliding function of the brake calliper and does not obstruct brake calliper movement over the entire displacement path.
- Check the air connection for tightness.
- Perform a function and effectiveness test of the brake.

8 Appendix

8.1 WABCO tools


WABCO Basic Tools (tool kit 640 195 522 2)

Required for all WABCO compressed-air disc brakes

Item	Name	Notation
10	Handle	
11	Adapter	
12	Ring spanner / Ratchet spanner	
13	Renewal	

WABCO tools for PAN[®]19 (tool kit 640 195 521 2)

The WABCO Basic Tools (tool kit 640 195 522 2) are also required.

Item	Name	Notation
21	Drive-out bushing	
22	Drive-in bushing long 1	
25	Drive-in bushing long 2	
26	Drive-in bushing short	
27	Drive-in bushing cover	
28*	Drive-in bushing short*	

*) This tool is part of the tool kit but is not required for the brake type PAN[®]19.

8.2 Widths across flats and tightening torques

(Also see drawing on the next page)

Do not use motor-driven screw or torque tools!

Item	Name	Width across flats Hexagon screw		Tightening torque (Nm) Remarks
		external	inside	
I	Hexagon adjuster	8	–	Direction of rotation on the hexagon: - Adjust, anti-clockwise (left) maximum 3 Nm, clearance decreases. - Restore, clockwise (right), maximum 12 Nm, clearance increases.
II	Screw for lining retainer	17	–	40 + 5 Nm
III	Brake fastening screwed connection	24	–	Recommended: 290 ±20 Nm Always observe the relevant specifications of the axle or vehicle manufacture!
IV	Couplings, guide pins	–	14	130 Nm + 90° (angle controlled tightening) Tightening sequence for guide pins: 1. Fit bolt, long (with hexagon socket screw) 2. Play bolt, short (with hexagon socket screw)
V	Couplings, brake cylinder	24	–	210 – 30 Nm ¹⁾ - Screw on the fastening nuts manually till the brake cylinder rests against the surface. - Tighten the fastening nuts with approx. 120 Nm. - Tighten fastening nuts with 210 – 30 Nm. Only use fastening nuts once!

¹⁾ The tightening torques apply for original WABCO cylinders




Fig. Illustration of positions for widths across flats and tightening torques

8.3 Exploded view of the replacement parts

Information and publications on WABCO repair kits and service documents can be found in the product catalogue INFORM on the Internet at www.wabco-auto.com




Fig. Illustration of replacement parts for a left brake

- | | | | |
|------|--|----|--|
| 1 | preassembled brake calliper (1) with actuating unit, with brake anchor plate (2) and pressure plate (19) | 12 | Closing plug of the adjuster |
| 4 | Bushings for guide pins | 13 | Protection cap for the hexagon of the adjuster |
| 5 | Protection caps for guide pins | 19 | Spreader plate |
| 6 | Hexagon socket screw | 35 | Brake lining rim side |
| 8 | Guide pin (long) | 36 | Brake lining cylinder side |
| 9 | Guide pin (short) | 37 | Hold-down springs |
| 10 | Protection cap for adjuster screw | 38 | Lining retainer |
| 11 | Closing cover (short) | 39 | Hexagon screw |
| 11.1 | Closing cover (long) | 40 | Cable guide with wear indicator |
| | | 41 | Cable clips |

8.4 Procurement and disposal of spare parts

8.4.1 Procurement of spare parts

- Identify the brake by means of the WABCO part number.



Fig. WABCO type plate

- A Vehicle manufacturer part number
- B Date of production
- C Assembly number
- D WABCO part number

- Open INFORM at www.wabco-auto.com
- Enter the WABCO part number of the brake calliper.
- Click on "Repair".
- Open the spare part sheet.

8.4.2 Disposing of the brake components

- Dispose of used and replaced parts in accordance with the national and regional regulations regarding environmental protection.

Generally brake components can be scrapped.

WABCO Spare Parts List Disc Brakes 40 195 001 - Microsoft Internet Explorer

Address: <http://www.wabco.info/en/Inform.asp?keyword=40+195+001&selected=1>

Index - Product number - Publications - Vehicles - Components Technical sheets - Cross Reference

WABCO: Product Catalog: Spare Parts List

Disc Brakes 40 195 001 [Back](#)

Edition: 01/06 [Drawing \(1 of 1\)](#) [Download Viewer](#)

Repair kit 12 999 737 Brake pads, for two brakes
 Repair kit 12 999 738 Seals and guide bolt
 Repair Unit 12 999 755 Wear indicator, for two brakes

When changing brake pads, indicators must be ordered separately
When changing the bolts requires tool case 12 851 821

Description	Order Number	Position	Quantity	Quantity in Repairkit
Brake lining support	-	1 *	2	4 12 999 737
Leaf spring	-	2 *	3	6 12 999 737
Hexagon Bolt	-	3 *	1	2 12 999 737
Strap	-	4 *	1	2 12 999 737
Plug/Locking Screw	-	5 *	1	1 12 999 738
Plug/Locking Screw	-	5 *	1	1 12 999 737
Wear Indicator	-	6 -	2	2 12 999 755
pipe support	-	7 -	2	5 12 999 755
Cover	-	8 *	2	2 12 999 738
Screw	-	9 *	1	1 12 999 738
Screw	-	10 *	1	1 12 999 738
Pins	-	11 *	1	1 12 999 738
Pins	-	12 *	1	1 12 999 738
Bush	-	13 *	3	3 12 999 738
Protection plug	-	14 *	2	2 12 999 738
Gasket	-	15 *	1	1 12 999 738
exchange brake without pads	40 195 001	16 -	1 a	

Legend:
 * All Replace these parts should be replaced ** See spare parts list with this part number
 *** This part is not included in the repairkit and is to be ordered separately
 a To be used if necessary - Part not shown.

Copyright WABCO No part of this publication may be reproduced without our prior permission.



WABCO (NYSE: WBC) is a leading global supplier of technologies and control systems for the safety and efficiency of commercial vehicles. Founded over 140 years ago, WABCO continues to pioneer breakthrough electronic, mechanical and mechatronic technologies for

braking, stability and transmission automation systems supplied to the world's leading commercial truck, bus and trailer manufacturers. With sales of \$2.8 billion in 2011, WABCO is headquartered in Brussels, Belgium. For more information, visit <http://www.wabco-auto.com>



WABCO