

Error No. 11: Proportional Valve / Cylinder 1

An error of the proportional valve output or its cabling.

When using a two-cylinder hydraulic system the failure refers to cylinder 1. With the articulation system HNG 16.5 the cylinder 1 is located in travel direction left, and with the articulation system HG 15.3. From the serial number on the type label you can see what type of articulation system applies (e.g. 165).

