

Error No. 20: Proportional Valve 2

An error of the proportional valve output 2 or its cabling.

With the articulation system HNG 16.5 cylinder 2 is located in travel direction right, and with the articulation system HG 15.3. From the serial number on the type label you can see what type of articulation system applies (e.g. 165).

